


Overhang Support

There are three types of countertop support systems. Either is acceptable and depends on the desired design to be achieved.


The most important part is that the countertop overhang has proper support as it extends from the cabinet or knee wall. Proper support will help prevent tipping or stress to the countertop.

The first and more popular are hidden support brackets. The second are the decorative corbels either metal or wood.


Flat Bracket



L-Bracket



Corbe



Either system provides sufficient structural support for the countertop.

The type of support and number of supports needed depends on the material and length of the extended unsupported countertop.

There may be some exceptions to the countertop support requirement when the overhang is less than ten inches. This may occur when a natural stone is selected that may be extremely fragile.



Overhang Support

Bracket Size Determination:	Overhang Min.	Overhang Max
Countertop Bracket 12"	9"	11"
Countertop Bracket 15"	12"	14"
Countertop Bracket 20"	17"	19"
Island Bracket 33"	11"	16"

Cantilevered Weight Offset:

A 36" wide Top on a 24" Base Cabinet satisfies the 2/3 - 1/3 Rule as well as satisfying the cantilevered weight offset. When the desired overhang is greater than 1/3 of the Top, Brackets are required to support the overhang. However, this may not satisfy the cantilevered weight offset. At some point there is too much weight cantilevered and may pull a cabinet or wall over unless the base is well secured. This cantilevered weight is not limited to of the weight of the top but could be compromised by a persons weight or articles placed on the top causing a tipping point.

Bracket Requirements:

Minimum of 2-Brackets

Set Brackets 12" from each end of Top and then every 16" to 24" on center **Calculator:** Number of Brackets= (**Length** divided by **24**") + 1-Bracket Please note that when it comes to ledges on knee wall or half wall, generally speaking, the 2/3rd rule does not apply, and bracket support are almost always needed.

Note: Additional brackets may be needed due to the amount of overhang and fragility of the material as determined by the Lang Stone Drafting or Installation Team. When working with Lang Stone there is no requirement as to who supplies and/or installs countertop brackets.



Interior Stone Products / 4099 E 5th Avenue / Columbus, Ohio 43219 614.235.4099 / 1.800.589.LANG / langstone.com / Hours: M-F 8:00 am - 5:00 pm © 2021 Lang Stone Company





